


KENWOOD

SERVICE MANUAL

TH-21A/AT/E BT-2, DC-21, EB-2, PB-21, SC-8/8T, SMC-30, TU-6

2m FM HAND-HELD TRANSCEIVER



CONTENTS

CIRCUIT DESCRIPTION	2
PACKING	7
PARTS LIST	8
PC BOARD VIEWS	
SWITCH UNIT (X41-1590-XX)	18
TONE UNIT (X52-1270-XX) (TH-21E ONLY)	19
DTMF UNIT (TH-21AT ONLY)	19
RF UNIT (X44-1630-XX)	20
IF UNIT (X48-1410-XX)	22
DISASSEMBLY	23
LEVEL DIAGRAM	25
ADJUSTMENT	26
BT-2 (AAA MANGANESE/ALKALINE BATTERY CASE)	29
EB-2 (EXTERNAL C MANGANESE/ALKALINE BATTERY CASE)	29
PB-21 (Ni-Cd BATTERY)	29
DC-21 (DC-DC CONVERTER)	30
SC-8/8T (SOFT CASE)	30
SMC-30 (SPEAKER MICROPHONE)	31
TU-6 (PROGRAMABLE TONE ENCODER) (TH-21A/AT ONLY)	31
WIRING	32
REFERENCE DATA	32
SCHEMATIC DIAGRAM (TH-21A/AT)	33
SCHEMATIC DIAGRAM (TH-21E)	34
BLOCK DIAGRAM	35
SPECIFICATIONS	BACK COVER

Photograph shows TH-21AT type.

CIRCUIT DESCRIPTION

Model	Destination	Frequency range (MHz)	RPT-SHIFT Freq' (kHz)	TONE	Ref'
TH-21A	K1,M1,M2	144.00–147.995	±600	Option (TU-8)	DTMF System used
	X	144.00–145.995			
TH-21AT	K2,M3,M4	144.00–147.995			TRIO Brand
TH-21E	T	144.00–145.995	–600/REV	1750Hz TONE BURST	
	W			1750 Hz TONE	

K : U.S.A. M : Gen. T : England W : Europe X : Australia/Newzealand

Table 1 Destination chart

RX Section

The TH-21A/AT/E uses a double super-heterodyne type receiver with a IF frequency of 16.3MHz and a second IF frequency of 455kHz.

The received signal from the antenna is amplified by RF amplifiers Q1 : 2SC2176(H) and Q2 : 2SC2668(Y), which are in connected cascade, and applied to BPF L6–L8. The RF signal is then applied to the first mixer, Q3 : 2SK192A, where it is mixed with the first local oscillator signal from the PLL. The first mixer output passes through a 16.3MHz MCF (F1) and becomes the first IF signal. This signal is amplified by IF amplifier Q4 : 2SC2714(Y) and is applied to IF unit Q1 : MC3359P




Fig. 1 TA7331F Block diagram (IF unit Q2)

Item	Rating
Noninal center frequency (fo)	16.3MHz
Pass bandwidth	fo ± 7.5kHz or more at 3dB
Attenuation bandwidth	fo ± 25kHz or more at 18dB
Guaranteed attenuation	30dB or more within fo ± 1MHz Spurious: 15dB or more at fo ~ fo + 500kHz.
Ripple	0.5dB or less
Insertion loss	1.0dB or less
Terminal impedance	1kΩ/1.5pF

Table 2 MCF (L71-0426-05) (RF unit F1)

Item	Rating
Center frequency of 6dB bandwidth (fo)	455kHz ± 1.5kHz
6dB bandwidth	± 7.5kHz or more
40dB bandwidth	± 15kHz or less
Ripple	1.5dB or less (455 ± 5kHz)
Guaranteed attenuation	27dB or more within fo ± 100kHz
Insertion loss	6dB or less at 455kHz
Terminal impedance	1.5kΩ

Table 3 Ceramic filter (L72-0335-05) (IF unit F1)

Q1 consists of the second mixer, second local oscillator, second IF amp, FM demodulator, squelch noise amp and control circuits.

The demodulated audio signal from Q1 is amplified by AF amplifier Q2 : TA7331F, on the IF unit, via the AF volume control (VR1 on the switch unit) to drive the speaker.

The squelch circuit, (an auxiliary circuit of the receiver section) detects the high frequency noise component of the demodulated audio output from Q1.

This signal is applied to pin 12 of Q1 via the squelch control, (VR2 on the switch unit). The noise component applied to pin 12, is amplified and then output at pin 13. The output at pin 13 is rectified by D1 and D2 : 1N60As and fed to pin 14. When this rectified voltage is applied to pin 14, the squelch trigger circuit functions, pin 16 is grounded, and Q4 : 2SC2412K and Q3 : 2SB698(E,F) turn OFF. When Q3 turns OFF, AF amp IC Q2 : TA7331F is muted and no audio is output. When a signal is received, the noise level contained in the demodulated output of Q1 reduced, and the squelch trigger circuit does not function. Therefore, Q4 and Q3 turn ON, the AF amp IC is powered, and audio output is obtained.

CIRCUIT DESCRIPTION




Fig. 2 Squelch-mute circuit

TX Section

The VCO local oscillator Q14 : 2SC2714(Y) frequency in transmit is one half the actual TX frequency. The output of VCO buffer amp Q16 : 2SC2671(H) is doubled by Q5 : 2SC2668(Y) and fed through a BPF to obtain the TX frequency. The output of the BPF is fed to pre-driver, Q6 : 2SC2347, driver Q7 : 2SC2053, and is then amplified by the final amplifier Q8 : 2SC1947.

	VCBO	VEBO	VCE0	IC	PC	PC	Tj	Tstg	Ta
Test Conditions			RBE = ∞ Ω		Tc = 25°C	Ta = 25°C			25 ± 3°C
Maximum Rating	35V	4V	17V	1A	10W	1W	+175°C	-65 ~ +175°C	

Table 4 2SC1947 Max. rating (RF unit Q8)

Signals from the microphone and the tone circuits are amplified by mic amp Q6 : NJM4558M. The signal is then applied to voltage variable capacitor diode D16 : 1S2208 of the VCO circuit to modulate the VCO signal. The transmitter section also consists of the power selector circuit and the tone circuit.

To select the power, the emitter resistor R23 (10Ω) of driver Q7 is controlled by the HI/LO switch (S1) on the IF unit. When R23 is grounded, the output power is about 1W. When R23 is opened, the output power becomes about 150mW.




Fig. 3 Power select circuit

Several different tone circuits are available to provide access to repeaters. Circuits vary depending on country of destination.

- 1) In E (W) type models (for European countries), when the TONE switch (a non-locking type) is held depressed, the radio enters TX mode and a tone signal of 1750Hz is emitted.
- 2) In E (T) type models (for the United Kingdom), when the TONE switch is pressed, the radio will enter TX mode and a tone burst of 1750Hz is transmitted.
- 3) The optional tone encoder (TU-6) may be installed in A/AT versions. With the TU-6, any one of 37 frequencies between 67.0–250.3Hz can be transmitted. When the TONE switch is pressed, the tone signal is continuously transmitted.
- 4) In AT type models, a DTMF (Dual-Tone Multi Frequency) system is also used. When a key is pressed, the unit enters TX mode and transmits a dual tone signal as long as the key is held depressed.

CIRCUIT DESCRIPTION

PLL Circuit

In RX mode, the VCO oscillates at frequency of 1/2 the first local oscillator [63.85 – 65.8475MHz (T,W,X ; 63.85–64.845MHz)]. In TX mode, the VCO oscillates at a frequency of 1/2 the TX frequency [72–73.9975MHz (T,W,X ; 72 – 72.9975MHz)].

During reception, D15 turns ON to connect C104 into the oscillator circuit which causes the oscillation frequency of the VCO to drop.




Fig. 4 VCO circuit

The output of the VCO is amplified by Q15: 2SC2714(Y) and mixed with the HET oscillator Q9: 2SC2714(Y) signal by PLL mixer Q10: 2SC2668(Y).


The frequency of the HET oscillator is determined by the crystal selected by the OFFSET switch. Q9 in connection with BPF L25 and L26 acts as a frequency doubler.

The output of PLL mixer Q10 passes through a LPF (L28, C79, C80) to obtain a 2–3.995MHz signal (T,W,X ; 2–2.995MHz). This signal is amplified by Q11: 2SC2668(Y) and is applied to programmable counter Q3: TC9122P. The signal input to Q11 is divided by 1/400 at 144.00MHz and 1/799 at 147.99MHz (T,W,X ; 1/599 at 145.99MHz). The actual divide ratio is determined by the thumb-wheel switch, (S2) on switch unit, settings.


The output of Q3 is compared with the (5kHz) reference signal by the phase comparator Q13: TC5081AP. The 10.24MHz reference oscillator signal is divided by 1/2048 in Q12: TC5082P to obtain the phase comparator reference frequency. The control voltage output of Q13 is fed through a passive type LPF to voltage variable capacitor diode D14: ITT310TE of VCO circuit to control the VCO frequency.

Peripheral circuits of the PLL are the +5kHz circuit, and PLL unlock circuits. The +5kHz circuit is used to obtain the 5kHz TX and RX frequencies. In RX mode, when the 5k switch, S3 on switch unit, is set to off, D6 of the PLL HET oscillator circuit is forward biased effectively by passing. When the 5k switch is set to ON, the D6 turns off, which connects TC4 and C61 to crystal (X2) in series.

When a capacitor is connected to the crystal in series, the frequency of oscillation increases. Use TC4 to adjust the +5kHz frequency. The PLL unlock circuit is described in the control circuit section.



CIRCUIT DESCRIPTION



A	TH-21A/AT			K,M,X Type			TH-21E			T,W Type		
	OFF SET Switch			Crystal			OFF SET Switch			Crystal		
		—	S	+	X2	61.850MHz		—	S	REV	X2	61.850MHz
		(600kHz)		(600kHz)	X3	70.300MHz		(600kHz)			X3	61.550MHz
RX	X2	X2	X2	X4	70.000MHz		RX	X2	X2	X3	X4	70.000MHz
TX	X5	X4	X3	X5	69.700MHz		TX	X5	X4	X4	X5	69.700MHz

Fig. 6 Frequency configuration




Fig. 7 Thumb wheel switch (S59-3401-05) (Switch unit S2)

CIRCUIT DESCRIPTION

Control circuit

A constant regulated 5V is obtained from voltage regulator Q19 : LV517. The 5C signal is available in both TX and RX modes, and is used as a reference voltage on the 6R and 5T AVR's.

The 6R output of Q20 : 25C1037K is supplied to the RX section and the 5T output is supplied to the TX section. When the PTT switch is pressed, Q7 : 2SA1037K and Q8 : 2SA2412K are forward biased, and the TC line is grounded to place the radio in transmit mode.

The function of the power supply circuit is described in the table below.

	TC	Q23	Q26	Q22	Q24	6R	5T
RX	H	ON	OFF	ON	OFF	○	X
TX	L	OFF	ON	OFF	ON	X	○

Table 5 Function of power supply circuit

In unlock mode (when PLL is unlocked), the unlock signal "H" is felt at pin 1 of Q13 : TC5081AP. The unlock signal passes through D17 : MA152WA/2, to control Q23 and Q26 and switches the radio to RX. When a frequency is selected outside the normal amateur band, the anti-lock signal (AL) "H" is generated in the switch unit and is applied to D22 : 1SS133 of RF unit, which also places the radio in RX.

When the unlock or anti-lock signal is generated, an logic "H" is fed to the MUT pin (of the IF unit) through D17/2 or D18 : 1SS133 to stop AF amp operation.

During transmit, the 5T signal is replies to IF unit Q5 : 2SC2412K and Q1 : MC3359P via D4 : MA152WA to stop AF amp operation.




Fig. 8 Control circuit

CIRCUIT DESCRIPTION/PACKING

Parts No.	W09-0334-05	W09-0335-05	W09-0336-05	W09-0339-05
Input power	AC 120V 60Hz 3W or less	AC 220V 60/60Hz 3W or less	AC 240V 50Hz 3W or less	AC 240V 50/60Hz 3W or less
Output	DC 8.7V 32mA at 0mA/13.5V or less			
Weight	Approx. 120g	Approx. 210g		
Destination	U.S.A	Europe/Gen. M1-4	United Kingdom	Australia/ Newzealand
Ref.			TRIO Brand	

Table 6 Charger specifications





Fig. 9 Charger schematic diagram

PACKING



PARTS LIST


CAPACITORS

CC	45	TH	1H	220	J
1	2	3	4	5	6

- 1 = Type ceramic, electrolytic, etc. 4 = Voltage rating
2 = Shape round, square, etc. 5 = Value
3 = Temp. coefficient 6 = Tolerance

• Temperature Coefficient

1st Word	C	L	P	R	S	T	U
Color*	Black	Red	Orange	Yellow	Green	Blue	Violet
ppm/°C	0	-80	-150	-220	-330	-470	-750



• Capacitor value

- 0 1 0 = 1pF
1 0 0 = 10pF
1 0 1 = 100pF
1 0 2 = 1000pF = 0.001μF

1 0 3 = 0.01μF

2 2 0 = 22pF
1st number Multiplier
2nd number

• Tolerance

Code	C	D	G	J	K	M	X	Z	P	No code
(%)	± 0.25	± 0.5	± 2	± 5	± 10	± 20	+ 40 - 20	+ 80 - 20	+ 100 - 0	10μF-10~+50 4.7μF-10~+75

Code	B	C	D	F	G
(pF)	± 0.1	± 0.25	± 0.5	± 1	± 2


Example CC45TH = -470±60 ppm/°C

Less than 10 pF


• Rating voltage

2nd word 1st word	A	B	C	D	E	F	G	H	J	K	V
0	1.0	1.25	1.6	2.0	2.5	3.15	4.0	5.0	6.3	8.0	-
1	10	12.5	16	20	25	31.5	40	50	63	80	35
2	100	125	160	200	250	315	400	500	630	800	-
3	1000	1250	1600	2000	2500	3150	4000	5000	6300	8000	-


• Chip capacitors



• Chip resistor (Carbon)



• Carbon resistor (Normal type)



- 1 = Type ceramic, electrolytic, etc.
2 = Shape round, square, etc.
3 = Dimension
4 = Temp. coefficient
5 = Voltage rating
6 = Value
7 = Tolerance.

Dimension

Dimension code	L	W	T
Empty	5.6 ± 0.5	5.0 ± 0.5	Less than 2.0
E	3.2 ± 0.2	1.6 ± 0.2	Less than 1.25
F	2.0 ± 0.3	1.25 ± 0.2	Less than 1.25

Dimension

Dimension code	L	W	T	Wattage
E	3.2 ± 0.2	1.6 ± 0.2	0.57	2B
F	2.0 ± 0.3	1.25 ± 0.2	0.45	2A

Rating wattage

Cord	Wattage	Cord	Wattage	Cord	Wattage
2A	1 10W	2E	1 4W	3A	1W
2B	1 8W	2H	1 2W	3D	2W
2C	1 6W				

Dimension



Model	Destination	Switch unit	RF unit	IF unit	Tone unit	Touch tone unit
TH-21A	K1 · M1 M2 · X	X41-1590-11 X41-1590-71	X44-1630-11 X44-1630-71	X48-1410-11		
TH-21AT	K2 · M3 M4	X41-1590-11 X41-1590-71	X44-1630-11 X44-1630-71	X48-1410-11		A09-0402-05
TH-21E	T W	X41-1590-51 X41-1590-61	X44-1630-61	X48-1410-61	X41-1270-51 X41-1270-60	

PARTS LIST

TH-21A/AT/E GENERAL

N : New parts

* : Please note that parts are sometimes not in stock and it takes much time to deliver.

PART. NO	NOTE	NAME & DESCRIPTION	DISTINCTION & QUANTITY											REFERENCE. NO
			011	012	021	022	023	024	051	061	071			
A02-0670-02	N*	CASE(TOP) 144MHZ.KENWOOD	1		1	1								DISTINCTION K1 - 011 K2 - 012 M1 - 021 M2 - 022 M3 - 023 M4 - 024 T - 051 W - 061 X - 071
A02-0671-02	N*	CASE(TOP) 144MHZ. TRIO							1	1	1			
A02-0670-02	N*	CASE(TOP) 144MHZ.KENWOOD												
A02-0672-01	N*	CASE(TOP) 146MHZ.KENWOOD	1	1	1	1	1	1	1	1	1			
A02-0675-02	N*	CASE(BOTTOM)	1	1	1	1	1	1	1	1	1			
A09-0407-03	N*	CASE(TOP)ASS'Y 144MHZ.KENWOOD	1											
A09-0402-05	N*	CASE(TOP)ASS'Y * WITH DTMF												
A09-0407-03	N*	CASE(TOP)ASS'Y 144MHZ.KENWOOD												
A09-0402-05	N*	CASE(TOP)ASS'Y * WITH DTMF												
A09-0407-03	N*	CASE(TOP)ASS'Y 144MHZ. TRIO							1	1	1			
A09-0408-03	N*	CASE(TOP)ASS'Y 144MHZ. TRIO												
A09-0407-03	N*	CASE(TOP)ASS'Y 144MHZ.KENWOOD	1	1	1	1	1	1	1	1	1			
A21-0768-02	N*	ORNAMENTAL PANEL												
B04-0408-04	N*	SP METAL	1											
B04-0409-04	N*	SP METAL	1											
B04-0408-04	N*	SP METAL												
B04-0409-04	N*	SP METAL												
B04-0408-04	N*	SP METAL												
B05-0733-04	N*	SP GRILE	1	1	1	1	1	1	1	1	1			
B40-3510-04	N*	MODEL NAME PLATE TH-21A	1											
B40-3534-04	N*	MODEL NAME PLATE TH-21AT	1											
B40-3510-04	N*	MODEL NAME PLATE TH-21A												
B40-3534-04	N*	MODEL NAME PLATE TH-21AT												
B40-3535-04	N*	MODEL NAME PLATE TH-21E												
B40-3510-04	N*	MODEL NAME PLATE TH-21A	1						1	1	1			
B42-2343-04	N*	FCC PLATE												
B42-2359-04	N*	FCC PLATE	1	1										
B42-2343-04	N*	FCC PLATE												
B42-2359-04	N*	FCC PLATE												
B42-1745-04	N*	SERIAL NO. LABEL	1	1	1	1	1	1	1	1	1			
B42-2366-04	N*	PLATE HI/LO-- S +	1	1	1	1	1	1	1	1	1			
B42-2379-04	N*	PLATE HI/LO-- S REV	1	1	1	1	1	1	1	1	1			
B42-2366-04	N*	PLATE HI/LO-- S +												
B43-1025-04	N*	BADGE TH-21A	1											
B43-1029-04	N*	BADGE TH-21AT	1	1										
B43-1025-04	N*	BADGE TH-21A												
B43-1029-04	N*	BADGE TH-21AT												
B43-1032-04	N*	BADGE TH-21E												
B43-1025-04	N*	BADGE TH-21A												
B50-4123-00	N	INSTRUCTION MANUAL	1	1	1	1	1	1	1	1	1			
B50-4124-00	N	INSTRUCTION MANUAL												
B50-4123-00	N	INSTRUCTION MANUAL												
CC455L1H560J		CERAMIC 56P 50V	1	1	1	1	1	1	1	1	1			C 101 C 6, 7 C 2, 4 C 5 C 1, 3
CC73FCH1H300J		CHIP CAP. 30P 50V	2	2	2	2	2	2	2	2	2			
CE04CW0J100M		ELECTRO 10 6.3V	2	2	2	2	2	2	2	2	2			
CE04CW1C47M		ELECTRO 4.7 16V	2	2	2	2	2	2	2	2	2			
CK73FB1E103K		CHIP CAP. 0.01 25V	2	2	2	2	2	2	2	2	2			
E23-0432-04		TERMINAL FOR JUNCTION												
E23-0458-04	N	TERMINAL (INSIDE)												
E23-0432-04		TERMINAL FOR JUNCTION	2	2	2	2	2	2	2	2	2			
E23-0458-04	N	TERMINAL (INSIDE)												
F10-1316-04	N*	SHIELDING PLATE	1	1	1	1	1	1	1	1	1			
F19-0637-04	N*	SWITCH MASK(A) HI/LO	1	1	1	1	1	1	1	1	1			
F19-0638-04	N*	SWITCH MASK(B) OFFSET	1	1	1	1	1	1	1	1	1			

PARTS LIST

PART NO	NOTE	NAME & DESCRIPTION	DISTINCTION & QUANTITY												REFERENCE NO
			Q11	Q12	Q21	Q22	Q23	Q24	Q51	Q61	Q71				
F20-0520-04	*	CUSHION(B) SP	1	1	1	1	1	1	1	1	1				
F20-0538-04	N*	INSULATING BOARD	1	1	1	1	1	1	1	1	1				
GL9PR24	N	LED	1	1	1	1	1	1	1	1	1				D , 101
G10-0633-04	N*	TAPE RED	2	2	2	2	2	2	2	2	2				
G13-0802-04	N*	CUSHION FOR JUNCTION RF UNIT	1	1	1	1	1	1	1	1	1				
G13-0626-04	*	CUSHION MIC	1	1	1	1	1	1	1	1	1				
G13-0802-04	N*	CUSHION FOR JUNCTION	2	2	2	2	2	2	2	2	2				
G13-0803-04	N*	CUSHION(B) FOR PTT	1	1	1	1	1	1	1	1	1				
H01-4557-13	N*	CARTON(INSIDE)	1												
H01-4558-13	N*	CARTON(INSIDE)	1												
H01-4557-13	N*	CARTON(INSIDE)			1										
H01-4558-13	N*	CARTON(INSIDE)					1								
H01-4575-13	N*	CARTON(INSIDE)													
H01-4580-13	N*	CARTON(INSIDE)													
H01-4557-13	N*	CARTON(INSIDE)													
H10-2591-02	N*	PACKING FIXTURE(TOP)	1		1	1			1	1	1				
H10-2592-02	N*	PACKING FIXTURE(BOTTOM)	1	1	1	1	1	1	1	1	1				
H10-2598-02	N*	PACKING FIXTURE(TOP)	1	1	1	1	1	1	1	1	1				
H25-0703-14	*	BAG(TH-21 BODY)140X190	1	1	1	1	1	1	1	1	1				
H25-0029-04	*	BAG(ACS) 60X110	1	1	1	1	1	1	1	1	1				
H25-0103-04	*	BAG(CHARGER) 125X250	1	1	1	1	1	1	1	1	1				
H25-0096-04	*	BAG(BATTERY) 100X110	1	1	1	1	1	1	1	1	1				
J25-3251-05	N	FLEXIBLE PC BOARD RF-IF	1	1	1	1	1	1	1	1	1				
J32-0785-04	N	ROUND BOSS M2X6	2	2	2	2	2	2	2	2	2				
J39-0409-14	*	MIC SPACER	1	1	1	1	1	1	1	1	1				
J69-0306-04	N	HAND STRAP (ACS)	1	1	1	1	1	1	1	1	1				
J69-0309-05	N	O RING AF.SQL	2	2	2	2	2	2	2	2	2				
K27-0468-04	N	PUSH KNOB(A) TONE	1	1	1	1	1	1	1	1	1				
K27-0469-04	N	PUSH KNOB(B) +5KHZ	1	1	1	1	1	1	1	1	1				
K29-3012-04	N	KNOB(A) AF	1	1	1	1	1	1	1	1	1				
K29-3013-04	N	KNOB(B) SQL	1	1	1	1	1	1	1	1	1				
K29-3014-04	N	PTT LEVER	1	1	1	1	1	1	1	1	1				
LR40872	N	IC	1												Q , 3
L78-0010-05	N	CRISTAL 3.58MHZ	1												K , 1
N09-0683-05	N	SPECIAL SCREW M2 X4	2	2	2	2	2	2	2	2	2				
N30-2004-41	N	PAN HD SCREW(SWITCH PC BOARD)	1	1	1	1	1	1	1	1	1				
N33-2005-45	N	ROUND FLAT SCREW(CASE:TOP)	3	3	3	3	3	3	3	3	3				
N33-2008-45	N	ROUND FLAT SCREW(CASE:TOP)	1	1	1	1	1	1	1	1	1				
N35-2005-45	N	BIND SCREW(CASE:BOTTOM)	2	2	2	2	2	2	2	2	2				
RD73FB2A473J	N	CHIP RES. 47K OHM 1/10W	5						5	5					R , 1, 2, 3, 4, 5
RD73FB2A154J	N	CHIP RES. 150KOHM 1/10W	1						1	1					R , 6
R12-3449-05	N	TRIM.POT 10K	1						1	1					VR , 1
T07-0235-05	N	SPEAKER	1	1	1	1	1	1	1	1	1				
T18-0054-05	N	EARPHONE (ACS)	1	1	1	1	1	1	1	1	1				
T90-0340-05	N	HERICAL ANTENNA(ACS)	1	1	1	1	1	1	1	1	1				
T91-0312-15	N	ELECTRIC CONDENSER MIC	1	1	1	1	1	1	1	1	1				
W09-0334-05	N	BATTERY CHARGER ASS'Y 120V	1	1	1	1	1	1	1	1	1				
W09-0335-05	N	BATTERY CHARGER ASS'Y 220V	1	1	1	1	1	1	1	1	1				

PARTS LIST

PART. NO	NOTE	NAME & DESCRIPTION	DISTINCTION & QUANTITY												REFERENCE. NO
			011	012	021	022	023	024	051	061	071				
W09-0336-05	N	BATTERY CHARGER ASS'Y 240V							1						
W09-0335-05	N	BATTERY CHARGER ASS'Y 220V								1					
W09-0339-05	N	BATTERY CHARGER ASS'Y 240V									1				
W09-0333-05	N	NI-CD BATTERY ASS'Y	1	1	1	1	1	1	1	1	1				
X41-1590-11	N*	SWITCH UNIT	1	1	1										
X41-1590-71	N*	SWITCH UNIT				1									
X41-1590-11	N*	SWITCH UNIT					1								
X41-1590-71	N*	SWITCH UNIT						1							
X41-1590-51	N*	SWITCH UNIT							1						
X41-1590-61	N*	SWITCH UNIT								1					
X41-1590-71	N*	SWITCH UNIT									1				
X44-1630-11	N*	RF UNIT	1	1	1										
X44-1630-71	N*	RF UNIT				1									
X44-1630-11	N*	RF UNIT					1								
X44-1630-71	N*	RF UNIT						1							
X44-1630-61	N*	RF UNIT							1						
X44-1630-71	N*	RF UNIT								1					
X48-1410-11	N*	IF UNIT	1	1	1	1	1	1							
X48-1410-61	N*	IF UNIT							1						
X48-1410-11	N*	IF UNIT								1					
X52-1270-51	N*	IF UNIT									1				
X52-1270-60	N*	IF UNIT										1			
2SA1037K(Q)		CHIP TR.											Q	2	
2SA1162(Y)		CHIP TR.											Q	2	
2SC2412K(Q)		CHIP TR.											Q	1	
2SC2712(Y)		CHIP TR.											Q	1	

SEMICONDUCTOR

Item	Re- marks	Part No.
Diode		1S1555
		1S2588
		1SS133
		BA282
Vari-cap		MA856
		MI301
		1S2208
Zener Diode		ITT310TE
		MTZ6.8JB
LED		GL9PR24
Chip Diode		MA152WA
		MA152WK

Item	Re- marks	Part No.
TR		2SB698(E,F)
		2SC1947
		2SC2053
		2SC2347
		2SC2668(Y)
Chip TR		2SC2671(H)
		2SA1037K(Q)
		2SA1037K(R)
		2SA1162(G)
		2SA1162(Y)
FET		2SC2412K(Q)
		2SC2712(Y)
		2SC2714(Y)
		2SK192A(Y)

Item	Re- marks	Part No.
IC		LR40872
		LVC517
		MC3359P
		NJM555M
		NJM4558M
		TA7331F
		TC5081AP
		TC5081P
		TC5082P
		TC9122P

PARTS LIST

SWITCH UNIT (X41-1590-XX) (-11 : K1,K2,M1,M3 -51 : T -61 : W -71 : M2,M4,X)

PART NO	NOTE	NAME & DESCRIPTION	DISTINCTION & QUANTITY										REFERENCE NO
			011	051	061	071	14	14	14	14			
CK73FB1H102K		CHIP CAP. 1000P 50V	1	1	1	1	1	1	1	1			R 1, 2, 3, 4, 5, 6, 7 8, 9, 10, 11, 12, 13, 14
L33-0682-05	N	CHOKE COIL	1	1	1	1	1	1	1	1			L 1
L92-0110-05		FERRITE CORE	1	1	1	1	1	1	1	1			L 2
MA152WK		CHIP DIODE	2	2	2	2	2	2	2	2			D 4, 5
RD14CB2C101J		RES. CARBON 100 OHM 1/6W	1	1	1	1	1	1	1	1			R 11
RD14CB2C101J		RES. CARBON 100 OHM 1/6W	1	1	1	1	1	1	1	1			R 5
RD14CB2C103J		RES. CARBON 10K OHM 1/6W	1	1	1	1	1	1	1	1			R 2
RD14CB2C103J		RES. CARBON 10K OHM 1/6W	1	1	1	1	1	1	1	1			R 2, 4
RD73FB2A473J		CHIP RES. 47K OHM 1/10W	1	1	1	1	1	1	1	1			R 1
RD73FB2A473J		CHIP RES. 47K OHM 1/10W	1	1	1	1	1	1	1	1			R 1, 3
RD73FB2A102J		CHIP RES. 1K OHM 1/10W	1	1	1	1	1	1	1	1			R 6
R05-3427-15	N	POTENTIOMETER 10K (B) WITH SW	1	1	1	1	1	1	1	1			VR 1
R05-3428-05	N	POTENTIOMETER 10K (B)	1	1	1	1	1	1	1	1			VR 2
R92-0670-05		CHIP RES. 0 OHM	3	3	3	3	3	3	3	3			R 7, 8, 9
R92-0670-05		CHIP RES. 0 OHM	4	4	4	4	4	4	4	4			R 7, 8, 9, 10
S40-2445-05		PJSH SWITCH(SELF LOCK)	2	2	2	2	2	2	2	2			S 3, 4
S40-2445-05		PJSH SWITCH(SELF LOCK)	1	1	1	1	1	1	1	1			S 3
S40-2446-05		PUSH SWITCH(NON LOCK)	1	1	1	1	1	1	1	1			S 4
S59-3401-05	N	THUMB WHEEL SWITCH	1	1	1	1	1	1	1	1			S 2
TC9122P		IC	1	1	1	1	1	1	1	1			Q 3
1SS133		DIODE	2	2	2	2	2	2	2	2			D 6, 9
1SS133		DIODE	1	1	1	1	1	1	1	1			D 6, 7
2SC2412K(Q)		CHIP TR.	1	1	1	1	1	1	1	1			Q 1
2SC2412K(Q)		CHIP TR.	2	2	2	2	2	2	2	2			Q 1, 2
2SC2712(V)		CHIP TR.	1	1	1	1	1	1	1	1			Q 1
2SC2712(V)		CHIP TR.	2	2	2	2	2	2	2	2			Q 1, 2

PARTS LIST

RF UNIT (X44-1630-XX) (-11 : K1,K2,M1,M3 -61 : T,W -71 : M2,M4,X)

PART-NO	NOTE	NAME & DESCRIPTION	DISTINCTION & QUANTITY				REFERENCE-NO
			O11	O61	O71		
BA282		DIODE	4	4	4		L 10, 11, 12, 13
BA282		DIODE					L 10, 12, 13, 23
CC45CH1H090D		CERAMIC 9P 50V	1	1	1		C 51
CC45CH1H150J		CERAMIC 15P 50V	1	1	1		C 52
CC73FCH1H330J		CHIP CAP. 33P 50V	2	2	2		C 28, 48
CC73FCH1H100D		CHIP CAP. 10P 50V	12		12		C 8, 12, 22, 25, 27, 32, 62
CC73FCH1H100D		CHIP CAP. 10P 50V					C 63, 64, 109, 113, 118
CC73FCH1H100D		CHIP CAP. 10P 50V	11				C 8, 12, 22, 25, 27, 32, 63
CC73FCH1H390J		CHIP CAP. 39P 50V	3	3	3		C 64, 109, 113, 118
CC73FCH1H010C		CHIP CAP. 1P 50V	4	4	4		C 42, 79, 80
CC73FCH1H1R3C		CHIP CAP. 1.5P 50V	2	2	2		C 26, 33, 92, 117
CC73FCH1H470J		CHIP CAP. 47P 50V	2	2	2		C 11, 13
CC73FCH1H120J		CHIP CAP. 12P 50V	2	2	2		C 35, 74
CC73FCH1H560J		CHIP CAP. 56P 50V	3	3	3		C 99, 116
CC73FCH1H030C		CHIP CAP. 3P 50V	1	1	1		C 70, 72, 103
CC73FCH1H680J		CHIP CAP. 68P 50V	2	2	2		C 49
CC73FCH1H050C		CHIP CAP. 5P 50V	5	5	5		C 40, 69
CC73FCH1H150J		CHIP CAP. 15P 50V	2	2	2		C 73, 75, 76, 100, 105
CC73FSL1H121J		CHIP CAP. 120P 50V	3	3	3		C 104, 158
CC73FCH1H070D		CHIP CAP. 7P 50V	2	2	2		C 3, 5, 119
CC73FCH1H180J		CHIP CAP. 18P 50V	3	3	3		C 4, 14
CC73FCH1H090D		CHIP CAP. 9P 50V	1	1	1		C 86, 87, 98
CC73FCH1H220J		CHIP CAP. 22P 50V	1	1	1		C 94
CC73FCH1H270J		CHIP CAP. 27P 50V	2	2	2		C 39, 50
CE04CW1A330M		ELECTRO 33 10V	1	1	1		C 133
CE04CW1A101M		ELECTRO 100 10V	2	2	2		C 132, 155
CE04CW1C100M		ELECTRO 10 16V	1	1	1		C 88
CE04CW1C47M		ELECTRO 4.7 16V	2	2	2		C 45, 159
CE04CW1C470M		ELECTRO 47 16V	1	1	1		C 120
CE04CW1E3R3M		ELECTRO 3.3 25V	1	1	1		C 134
CE04CW1V2R2M		ELECTRO 2.2 35V	1	1	1		C 156
CE04CW0J100M		ELECTRO 10 6.3V	1	1	1		C 91
CE04CW1H010M		ELECTRO 1 50V	1	1	1		C 121
CE04CW0J470M		ELECTRO 47 6.3V	1	1	1		C 122
CE04CW1E4R7M		ELECTRO 4.7 25V	1	1	1		C 128
CK73FB1H102K		CHIP CAP. 1000P 50V	64	64	64		C 1, 7, 9, 10, 18, 19, 21
CK73FB1H102K		CHIP CAP. 1000P 50V					C 23, 24, 29, 30, 31, 36, 37
CK73FB1H102K		CHIP CAP. 1000P 50V					C 38, 41, 44, 46, 47, 57, 67
CK73FB1H102K		CHIP CAP. 1000P 50V					C 68, 71, 77, 78, 82, 84, 85
CK73FB1H102K		CHIP CAP. 1000P 50V					C 89, 90, 93, 95, 96, 97, 106
CK73FB1H102K		CHIP CAP. 1000P 50V					C 107, 108, 110, 111, 112, 114, 115
CK73FB1H102K		CHIP CAP. 1000P 50V					C 125, 126, 129, 130, 131, 135, 136
CK73FB1H102K		CHIP CAP. 1000P 50V					C 137, 138, 139, 140, 141, 142, 144
CK73FB1H102K		CHIP CAP. 1000P 50V					C 145, 146, 147, 148, 149, 152, 153
CK73FB1H222K		CHIP CAP. 2200P 50V	1	1	1		C 157
CK73FB1H472K		CHIP CAP. 470P 50V	4	4	4		C 83
CK73FB1E103K		CHIP CAP. 0.01 25V	10	10	10		C 15, 17, 101, 102
CK73FB1E223K		CHIP CAP. 0.022 25V	2	2	2		C 53, 54, 55, 56, 58, 59, 60
CK73FB1H471K		CHIP CAP. 470P 50V	2	2	2		C 65, 66, 154
C05-0327-05		TRIMMER 20P	2	2	2		C 20, 150
C05-0320-05		TRIMMER 30P	5	5	5		C 6, 81
C90-0891-05		TANTALUM 4.7 16V	1	1	1		TC 2, 3
							TC 1, 4, 5, 6, 7
							C 151

PART. NO	NOTE	NAME & DESCRIPTION	DISTINCTION & QUANTITY										REFERENCE. NO
			011	061	071								
E13-0105-05	N	RCA RECEPTACLE ANT. J	1	1	1								J , 1
F11-0873-04	N*	SHIELD COVER (VCO)	1	1	1								
1TT310TE		VOLTAGE VARIABLE	1	1	1								D , 14
LVC517		IC	1	1	1								Q , 19
L19-0354-05	N	WIDE BAND TRANS 12T	1	1	1								L , 33
L32-0672-05		OSC COIL	4	4	4								L , 19, 20, 21, 22
L34-2226-05	N	TUNING COIL VCO 70MHZ	1	1	1								L , 30
L34-2223-05	N	TUNING COIL 140MHZ	11	11	11								L , 6, 7, 8, 10, 11, 12, 13
L34-2224-05	N	TUNING COIL 16.3MHZ	1	1	1								L , 25, 26, 35, 36
L34-2225-05	N	TUNING COIL 140MHZ	1	1	1								L , 9
L34-0892-05		COIL 2 10T	1	1	1								L , 5
L34-0893-05		COIL 3 4T	1	1	1								L , 4
L34-0894-05		COIL 3 5T	2	2	2								L , 2
L34-0895-05		COIL 3 6T	1	1	1								L , 16, 17
L34-1041-05		COIL 3 2T	1	1	1								L , 14
L34-1105-05	N	COIL 3 4T ANT	1	1	1								L , 15
L40-3382-17		INDUCTOR 0.33UH	1	1	1								L , 1
L40-1092-17		INDUCTOR 1UH	2	2	2								L , 34
L40-3391-17		INDUCTOR 3.3UH	1	1	1								L , 3, 18
L40-5691-17		INDUCTOR 5.6UH	1	1	1								L , 32
-40-1501-17		INDUCTOR 15UH	1	1	1								L , 31
-40-4701-17		INDUCTOR 47UH	5	5	5								L , 28
L40-1011-17		INDUCTOR 100UH	2	2	2								L , 29, 40, 41, 42, 43
L71-0246-05	N	MCF 16.3MHZ	1	1	1								L , 27, 37
L77-1234-05	N	XTAL 10.24MHZ	1	1	1								F , 1
L77-1235-05	N	XTAL 30.925MHZ RX(S)	1	1	1								X , 1
L77-1236-05	N	XTAL 35.000MHZ TX(S)	1	1	1								X , 2
L77-1239-05	N	XTAL 35.150MHZ TX(+)	1	1	1								X , 4
L77-1237-05	N	XTAL 30.775MHZ RX(-)	1	1	1								X , 3
L77-1239-05	N	XTAL 35.150MHZ TX(+)	1	1	1								X , 3
L77-1238-05	N	XTAL 34.850MHZ TX(-)	2	2	2								X , 5
L92-0110-05		FERRITE CORE	2	2	2								L , 38, 39
MA152WA		CHIP DIODE	2	2	2								D , 17, 21
MA856		DIODE	5	5	5								D , 6, 7, 8, 9, 15
NI301		DIODE	1	1	1								D , 4
RD14CB2C220J		RES. CARBON 22 OHM 1/6W	1	1	1								R , 26
RD14CB2C470J		RES. CARBON 47 OHM 1/6W	1	1	1								R , 22
RD14BB2C560J		RES. CARBON 56 OHM 1/6W	2	2	2								R , 9, 47
RD14CB2C223J		RES. CARBON 22K OHM 1/6W	1	1	1								R , 5B
RD14BB2C822J		RES. CARBON 8.2KOHM 1/6W	1	1	1								R , 13
RD14CB2C103J		RES. CARBON 10K OHM 1/6W	1	1	1								R , 56
RD14BB2C222J		RES. CARBON 2.2KOHM 1/6W	1	1	1								R , 34
RD14BB2C392J		RES. CARBON 3.9KOHM 1/6W	1	1	1								R , 35
RD14BB2C223J		RES. CARBON 22K OHM 1/6W	1	1	1								R , 16
RD14CB2C472J		RES. CARBON 4.7KOHM 1/6W	2	2	2								R , 99, 100
RD14BB2C104J		RES. CARBON 100KOHM 1/6W	1	1	1								R , 93
RD14BB2C334J		RES. CARBON 330KOHM 1/6W	1	1	1								R , 14
RD73FB2A330J		CHIP RES. 33 OHM 1/10W	1	1	1								R , 20
RD73FB2A271J		CHIP RES. 27 OHM 1/10W	1	1	1								R , 27
RD73FB2A222J		CHIP RES. 2.2KOHM 1/10W	6	6	6								R , 3, 8, 12, 49, 57, 66
RD73FB2A103J		CHIP RES. 10K OHM 1/10W	8	8	8								R , 48, 55, 62, 63, 78, 79, 85

PARTS LIST

PART. NO	NOTE	NAME & DESCRIPTION	DISTINCTION & QUANTITY					REFERENCE. NO
			011	061	071			
RD73FB2A473J		CHIP RES. 47K OHM 1/10W	4	4	4			R , 88
RD73FB2A331J		CHIP RES. 330 OHM 1/10W	2	2	2			R , 52, 83, 84, 94
RD73FB2A563J		CHIP RES. 56K OHM 1/10W	1	1	1			R , 43
RD73FB2A470J		CHIP RES. 47 OHM 1/10W	1	1	1			R , 17
RD73FB2A123J		CHIP RES. 12K OHM 1/10W	2	2	2			R , 89, 92
RD73FB2A560J		CHIP RES. 56 OHM 1/10W	1	1	1			R , 7
RD73FB2A471J		CHIP RES. 470 OHM 1/10W	4	4	4			R , 4, 6, 46, 50
RD73FB2A104J		CHIP RES. 100KOHM 1/10W	1	1	1			R , 54
RD73FB2A272J		CHIP RES. 2.7KOHM 1/10W	2	2	2			R , 2, 67
RD73FB2A153J		CHIP RES. 15K OHM 1/10W	2	2	2			R , 19, 59
RD73FB2A154J		CHIP RES. 150KOHM 1/10W	1	1	1			R , 72
RD73FB2A352J		CHIP RES. 3.3KOHM 1/10W	1	1	1			R , 77
RD73FB2A101J		CHIP RES. 100 OHM 1/10W	7	7	7			R , 1, 10, 18, 21, 64, 73, 73
RD73FB2A681J		CHIP RES. 680 OHM 1/10W	1	1	1			R , 11
RD73FB2A821J		CHIP RES. 820 OHM 1/10W	2	2	2			R , 45, 70
RD73FB2A183J		CHIP RES. 18K OHM 1/10W	1	1	1			R , 44
RD73FB2A224J		CHIP RES. 220KOHM 1/10W	2	2	2			R , 51, 82
RD73FB2A472J		CHIP RES. 4.7KOHM 1/10W	3	3	3			R , 76, 80, 86
RD73FB2A334J		CHIP RES. 330KOHM 1/10W	1	1	1			R , 65
RD73FB2A223J		CHIP RES. 22K OHM 1/10W	2	2	2			R , 81, 87
RD73FB2A2R2J		CHIP RES. 2.2 OHM 1/10W	1	1	1			R , 96
RD73FB2A122J		CHIP RES. 1.2KOHM 1/10W	3	3	3			R , 42, 91, 61
RD73FB2A562J		CHIP RES. 5.6KOHM 1/10W	7	7	7			R , 38, 39, 40, 41, 61, 68, 95
RD73FB2A121J		CHIP RES. 120 OHM 1/10W	2	2	2			R , 25, 69
RD73FB2A151J		CHIP RES. 150 OHM 1/10W	1	1	1			R , 24
RD73FB2A100J		CHIP RES. 10 OHM 1/10W	1	1	1			R , 23
RD73FB2A220J		CHIP RES. 22 OHM 1/10W	1	1	1			R , 28
RD73FB2A822J		CHIP RES. 8.2KOHM 1/10W	3	3	3			R , 5, 36, 37
R92-0670-05		CHIP RES. 0 OHM	2	2	2			R , 97, 98
R92-0150-05		JUMPER WIRE	1	1	1			JP , 1
S50-1425-05	N	TACT SWITCH PTT	1	1	1			S , 1
TC5082P		IC	1	1	1			Q , 12
TC5081AP	N	IC	1	1	1			Q , 13
1SS433		DIODE	4	4	4			D , 2, 19, 20, 24
1SS133		DIODE	1	1	1			D , 2, 18, 19, 20, 22, 24
1S1555		DIODE	1	1	1			D , 3
1S2588		DIODE	1	1	1			D , 5
1S2208		VOLTAGE VARIABLE	1	1	1			D , 16
2SA1037K(0)	N	CHIP TR.	2	2	2			Q , 20, 26
2SA1162(Y)		CHIP TR.	2	2	2			Q , 20, 26
2SA1037K(R)		CHIP TR.	2	2	2			Q , 22, 24
2SA1162(GR)		CHIP TR.	1	1	1			Q , 22, 24
2SB698(E,F)		TR	1	1	1			Q , 18
2SC2714(Y)		TR	4	4	4			Q , 4, 9, 14, 15
2SC1947		TR	1	1	1			Q , 8
2SC2053		TR	1	1	1			Q , 7
2SC2347		TR	1	1	1			Q , 6
2SC2668(Y)		TR	5	5	5			Q , 2, 5, 10, 11, 17
2SC2671(H)		TR	2	2	2			Q , 1, 16
2SC2412K(0)		CHIP TR.	4	4	4			Q , 21, 23, 25, 27
2SC2712(Y)		CHIP TR.	4	4	4			Q , 21, 23, 25, 27
2SK192A(Y)		FET	1	1	1			Q , 3

TH-21A/AT/E PARTS LIST

for free by
RadioAmateur.eu

IF UNIT (X48-1410-XX) (-11 : K1,K2,M1,M2,M3,M4,X -61 : T,W)

PART.NO	NOTE	NAME & DESCRIPTION	DISTINCTION & QUANTITY		REFERENCE.NO
			011/061		
CC73FCH1H270J		CHIP CAP. 27P 50V	1	1	C 3
CC73FSL1H101J		CHIP CAP. 100P 50V	5	5	C 2, 16, 36, 37, 38
CC73FSL1H151J		CHIP CAP. 150P 50V	1	1	C 9
CC73FSL1H391J		CHIP CAP. 390P 50V	1	1	C 47
CE04CW0J330M		ELECTRO 33 6.3V	1	1	C 43
CE04CW1A100M		ELECTRO 10 10V	2	2	C 40, 52
CE04CW1C47M		ELECTRO 4.7 16V	1	1	C 33
CE04CW1V2R2M		ELECTRO 2.2 35V	4	4	C 19, 21, 34, 44
CK45B1H102K		CERAMIC 1000P 50V	1	1	C 1
CK73FB1H102K		CHIP CAP. 1000P 50V	20	20	C 7, 12, 14, 15, 20, 29, 30, 31, 32, 35, 42, 49, 50, 51, 53, 54, 55, 56, 57, 58
CK73FB1E273K		CHIP CAP. 0.027 25V	1	1	C 23
CK73FB1H272K		CHIP CAP. 2700P 50V	1	1	C 45
CK73FF1F473Z		CHIP CAP. 0.047 25V	3	3	C 4, 8, 11
CK73FB1H682K		CHIP CAP. 6800P 50V	1	1	C 46
CK73FB1E223K		CHIP CAP. 0.022 25V	2	2	C 13, 17
C90-0888-05		TANTALUM 0.1 16V	1	1	C 39
C90-0889-05		TANTALUM 0.22 16V	1	1	C 10
C90-2006-05	N	TANTALUM 0.33 16V	1	1	C 48
C90-0894-05		TANTALUM 0.47 16V	1	1	C 18
C90-2007-05		TANTALUM 3.3 16V	1	1	C 22
C90-2012-05		ELECTRO 100 10V	3	3	C 25, 26, 28
C90-0891-05		TANTALUM 4.7 16V	1	1	C 24
C91-0488-05		CERAMIC 0.1	2	2	C 5, 6
C91-0430-05		LAYER CAP. 0.047	1	1	C 41
C91-1035-05		FILM CAP. 0.22 63V	1	1	C 27
F11-0420-05	N	MIC JACK	1	1	J 2
E11-0421-05	N	PHONE JACK	1	1	J 1
L34-2217-05		T-ING COIL 455KHZ	1	1	L 1
L72-0335-05		CERAMIC FILTER CPU-455E	1	1	F 1
L77-1240-05	N	CRYSTAL 15.845MHZ	1	1	X 1
MA152WA	N	CHIP DIODE	1	1	D 4
MC3359P		IC	1	1	Q 1
MT6.8.B		ZENER DIODE 6.8V	1	1	D 3
NJM4558M		IC	1	1	Q 6
RD14CB2C472J		RES. CARBON 4.7KOHM 1/6W	2	2	R 30, 31
RD14CB2C103J		RES. CARBON 10K OHM 1/6W	2	2	R 15, 17
RD14CB2C104J		RES. CARBON 100KOHM 1/6W	1	1	R 9
RD14CB2C684J		RES. CARBON 680KOHM 1/6W	1	1	R 20
RD73FB2A102J		CHIP RES. 1K OHM 1/10W	3	3	R 14, 16, 19
RD73FB2A152J		CHIP RES. 1.5KOHM 1/10W	1	1	R 29
RD73FB2A473J		CHIP RES. 47K OHM 1/10W	4	4	R 18, 36, 38, 39
RD73FB2A222J		CHIP RES. 2.2KOHM 1/10W	4	4	R 4, 26, 33, 34
RD73FB2A823J		CHIP RES. 82K OHM 1/10W	1	1	R 13
RD73FB2A273J		CHIP RES. 27K OHM 1/10W	1	1	R 35
RD73FB2A470J		CHIP RES. 47 OHM 1/10W	1	1	R 12
RD73FB2A104J		CHIP RES. 100KOHM 1/10W	1	1	R 10
RD73FB2A822J		CHIP RES. 8.2KOHM 1/10W	1	1	R 5
RD73FB2A336J		CHIP RES. 330KOHM 1/10W	1	1	R 6
RD73FB2A103J		CHIP RES. 10K OHM 1/10W	4	4	R 1, 7, 8, 27
RD73FB2A101J		CHIP RES. 100 OHM 1/10W	1	1	R 11

PART.NO	NOTE	NAME & DESCRIPTION	DISTINCTION & QUANTITY				REFERENCE.NO
			Q11	Q61			
RD73FB2A223J		CHIP RES. 22K OHM 1/10W	6	6			R 2, 3, 22, 23, 24, 37
RD73FB2A221J		CHIP RES. 220 OHM 1/10W	2	2			R 25, 32
RD73FB2A333J		CHIP RES. 33K OHM 1/10W	2	2			R 21, 28
R12-3449-05	N	TRIM.POT 10K	1	1			VR 1
R90-0526-05		RESISTOR BLOCK 27K OHM X4	1	1			RB 1
R92-1061-05		JUMPER WIRE	5				JP 1, 2, 6, 7, 8
		JUMPER WIRE					JP 3, 4, 6, 7, 8
S31-1414-05		SLIDE SWITCH HI - LO	1	1			S 1
S31-2409-05	N	SLIDE SWITCH OFFSET	1	1			S 2
TA7331F	N	IC	1	1			Q 2
1N60A		DIODE	2	2			D 1, 2
2SA1037K(G)	N	CHIP TR.	1	1			Q 7
2SA1162(Y)		CHIP TR.	1	1			Q 7
2SB698(E,F)		TR	1	1			Q 3
2SC2412K(G)	N	CHIP TR.	3	3			Q 4, 5, 8
2SC2712(Y)	N	CHIP TR.					Q 4, 5, 8


TONE UNIT (X41-1270-XX) (-51 : T -60 : W)

PART.NO	NOTE	NAME & DESCRIPTION	DISTINCTION & QUANTITY				REFERENCE.NO
			Q51	Q60			
CE04CW1C100M		ELECTRO 10 16V	1				C 7
CK73FB1H392K		CHIP CAP. 3900P 25V	1	1			C 6
CK73FB1E103K		CHIP CAP. 0.01 25V	3	3			C 2, 4, 5
CK73EB1E333K		CHIP CAP. 0.033 25V	1	1			C 3
NJM555M	N	IC	1	1			Q 1
RD73FB2A472J		CHIP RES. 4.7KOHM 1/10W	1	1			R 2
RD73FB2A123J		CHIP RES. 12K OHM 1/10W	2	2			R 4, 6
RD73FB2A333J		CHIP RES. 33K OHM 1/10W	1	1			R 7
RD73FB2A473J		CHIP RES. 47K OHM 1/10W	1	1			R 5
RD73FB2A913J		CHIP RES. 91K OHM 1/10W	1	1			R 3
R12-3452-05	N	TRIM.POT 20K	1	1			VR 1
R92-0670-05		CHIP RES. 0 OHM	1	1			R 8

TH-21A/AT/E PC BOARD VIEW

for free by
RadioAmateur.eu

SWITCH UNIT (X41-1590-XX) (-11 : K1,K2,M1,M3
-51 : T -61 : W -71 : M2,M4,X) Component side view




	Q2	D6,9	R3,4,10	JP4	JP5
K1, K2, M1, M3	X	X	X	X	X
M2, M4, X	O	X	O	O	O
T, W	O	O	O	O	X


O Used, X Not used

2SA1037
2SA1162
2SC2412
2SC2712

MA152WK




TONE UNIT (X52-1270-XX) (-51 : T -60 : W) Foil side view



Q1 NJM555M

DTMF UNIT (TH-21AT ONLY) Foil side view



Q1 . 2SC2412K(Q) or 2SC2712(Y)


Q2 2SA1037K(Q) or 2SA1162(Y)

Q3 LR40872

CASE (TOP) ASS'Y (A09-0402-05) WITH DTMF

Parts No.	Re- marks	Description	Q'ty	Ref. No.
A09-0672-01	N*	Case (Top) 146MHz, KENWOOD		
B42-2344-08	N*	Key board plate		
CC73CH1H300J		Chip cap. 30P 50V	2	C6,7
CE04CW0J100M		Electro 10 6.3V	2	C2,4
CE04CE1C4R7M		Electro 4.7 16V	1	C5
CK73FB1E103K		Chip cap. 0.01 25V	2	C1,3
LR40872	N	IC	1	Q3
L7B-0010-05	N	Crystal 3.58MHz	1	X1
RD73FB2A473J		Chip res. 47kΩ 1/10W	5	R1-5
RD73FB2A154J		Chip res. 150kΩ 1/10W	1	R6
R12-3449-05		Trim. pot. 10kΩ	1	VR1
2SA1037K(Q) or 2SA1162(Y)		Chip TR.	1	Q2
2SC2412K(Q) or 2SC2712(Y)		Chip TR.	1	Q1

RF UNIT (X44-1630-XX) (-11 : K1,K2,M1,M3 -61 : T,W -71 : M2,M4,X) Component side view




- Q1,16 2SC2677(H) Q2,5,10,11,17 2SC2668(Y) Q3,25K192A(Y) Q4,9,14,15 2SC2714(Y) Q6 2SC2347 Q7 2SC2053 Q8 2SC1947 Q12 TC5082P
 Q13 TC5081AP Q18 2SB698(L,F) Q19 LVC517 Q20,26 2SA1037K(O) or 2SA11C2(Y) Q21,23,25 27 2SC2412K(O) or 2SC2712(Y)
 Q22,24 2SA1037K(R) or 2SA1162(G)
 D2,19,20 1SS133 D3,24 1S1555 D4 M301 D5 1S2588 D6-8,15 MA856 D10,12,13 BA282 D11 K1,K2,M1,M2,M3,M4,X BA282 D14 1T1310TE
 D16 1S2208 D17,21 MA152WA D18,22 M2,M4,X,T,W 1SS133 D23 (T,W) BA282

	D11	D18 22	D23	JP5	C62
K1,K2,M1,M3	O	X	X	O	O
M2,M4,X	O	O	X	O	O
T,W	X	O	O	X	X

O Used, X Not used



RF UNIT (X44-1630-XX) (-11 : K1,K2,M1,M3 -61 : T,W -71 : M2,M4,X) Foil side view



2SC2053



2SB698
2SC2347



2SC2668



2SC2671



2SC1947



LVC517




2SK182A




TC5081AP
TC5082P



2SA1037K
2SA1162
2SC2412K
2SC2712
2SC2714



MA152WA




IF UNIT (X48-1410-XX) (-11 : K1,K2,M1,M2,M3,M4,X -61 : T,W) Component side view

- Q1 MC3359P
Q2 TA7331F
Q3 2SB698(E,F)
Q4,5,8 2SC2412K(Q) or
2SC2712(Y)
Q6 NJM4558M
Q7 2SA1037K(Q) or
2SA1162(Y)

- D*,2 1N60A
D3 MTZ6.8J8
D4 MA152WA

	JP1,2	JP3,4
K,M,X	○	X
T,W	X	○

○ : Used, X : Not used



IF UNIT (X48-1410-XX) (-11 : K1,K2,M1,M2,M3,M4,X -61 : T,W) Foil side view



2SB698



2SA1037K
2SA1162
2SC2412K
2SC2712





MA152WA



DISASSEMBLY

TOP CASE REMOVE METHOD



- ① Remove screw (M2 x 5) 3
- ② Remove front case as allow mark direction holding the stop pin with something  screw driver as shown right.



FRONT PANEL REMOVE METHOD


- ① Remove screw on RCA connector and AF, SQ knob.
- ② Remove screw (M2 x 8) 1.
- ③ Remove front panel by push stopper with screw driver as shown below.

TOOL



SHIELD COVER REMOVE METHOD

- ① Remove the top boss which tightened the IF unit.
- ② Remove solder at four spots with solder wick.
- ③ Remove solder heating spot with soldering iron.



TH-21A/AT/E DISASSEMBLY

for free by
RadioAmateur.eu

FCC plate
(B42-2343-04) **K1,M1,M2**
(B42-2359-04) **K2,M3,M4**

Bind screw x 2
(N35-2005-45)

Special screw x 2
(N09-D683-05)

Case (bottom)
(A02-0675-02)

Terminal (inside) x 2
(E23-0458-04)

Terminal for junction x 2
(E23-0432-04)

Cushion for junction x 2
(G13-0802-04)

IF unit
(X48-1410-11) **K1,K2,M1,M2,M3,M4,X**
(X48-1410-61) **T,W**

Switch mask (B)
(F19-0638-04)

Plate
(B42-2366-04) **K1,K2,M1,M2,M3,M4,T,X**
(B42-2379-04) **W**

Round boss x 2
(J32-0785-04)

Shielding plate
(F10-1314-04)

A Slide switch HI/LOW
(S31-1414-05)

Switch mask (A)
(F19-0637-04)

B Slide switch OFFSET
(S31-2409-05)

Mic jack EXT MIC
(E11-0420-05)

C Pan head screw
(N30-2004-41)

Phone jack EXT.SP
(E11-0421-05)

D Push knob (B) 5K
(K27-0469-04)

E Push knob (A) TONE
(K27-3012-04)

F Switch unit
(X41-1590-11) **K1,K2,M1,M3**
(X41-1590-51) **T**
(X41-1590-61) **W**
(X41-1590-71) **M2,M4,X**

Cushion (B)
(G13-0803-04)

Flexible PC board
(J25-3251-05)

Serial No. label
(B42-1745-04)

RF unit
(X44-1630-11) **K1,K2,M1,M3**
(X44-1630-61) **T,W**
(X44-1630-71) **M2,M4,X**

Shielding cover
(F11-0885-04)

RCA receptacle ANT
(E13-0165-05)

Tone unit
(X52-1270-51) **T**
(X52-1270-60) **W**

Model name plate
(B40-3510-04) **K1,M1,M2,X**
(B40-3534-04) **K2,M3,M4**
(B40-3535-04) **T,W**

Ornamental panel
(A21-0768-02)

Round flat screw
(N33-2008-45)

Knob (A) AF
(K29-3012-04)

Knob (B) SQL
(K29-3013-04)

O ring x 2
(J69-0309-05)

Electric condenser microphone
(T91-0312-15)

PTT lever
(K29-3014-04)

Mic spacer
(J39-0409-14)

Speaker
(T07-0235-05)

Case (top)
(A02-0670-02) **K1,M1,M2,W,X**
(A02-0671-02) **T**
(A02-0672-01) **K2,M3,M4**

Badge
(B43-1025-04) **K1,M1,M2,X**
(B43-1029-04) **K2,M3,M4**
(B43-1032-04) **T,W**



Round flat screw x 3
(N33-2005-45)

SP metal
(B04-0408-04) **K1,M1,M2,T,W,X**
(B04-0409-04) **K2,M3,M4**


SP grill cloth
(B05-0733-04)

LEVEL DIAGRAM

RX SECTION



TX SECTION




ADJUSTMENT

PREOPERATION

Unless otherwise specified. Set the controls as follows.

POWER/VOL OFF
HI/LOW HI
SQL MIN


- When adjusting the trimmers or coils, use a non-induced adjusting rod of bakelite, etc.
- When adjusting the RX section never transmit to prevent SSG damage.
- Connect MIC connector as shown right.
- Uses following RCA-BNC adaptor plug (MODEL AJ-3) for ANT connection.
- The output level of SSG is indicated as SSG's open circuit



MODEL AJ-3

BNC-J



RCA



TX/RX Section (Common)

Item	Condition	Measurement			Adjustment			Specification/ Remarks
		Test equipment	Unit	Terminal	Unit	Part	Method	
1. Voltage check	1) DC power supply . 7.2V	DC V.M	RF	FB				7.2V
	2) 5C			5C				5.0V
	3) 6R			6R				5.7V
	4) 5T PTT ON			5T				4.9V
	5) Receiver							



PLL Section

Item	Condition	Measurement			Adjustment			Specifications/ Remarks
		Test equipment	Unit	Terminal	Unit	Part	Method	
1. HET	1) f. any • Cut wire No.1 or connect to GND at Q15 collector on RF unit. • Turn L26 slug all the way inside.  OFFSET switch . "S"	RF VTVM	RF	TP3	RF	L25, 26	MAX Repeat couple times.	Approx. 7mVrms
	2) Connect D17 (or D22) cathode to GND via 100Ω resistor as shown right. Repeat each on TX/RX  RF UNIT						L26 Adjust to equal level on TX/RX	Approx. 4.5mVrms
2. PLL voltage setting	1) f = 141.00MHz	DC VM	RF	TP4	RF	L30	0.9V	0.9V±0.1V
	2) f = 144.00MHz, Transmit 3) Receive						Confirm	1.6V±0.2V
3. RX. f adjustment	1) f = 145.00MHz (T,W) f = 146.00MHz (K,M,X) OFF SET switch . "S"	f.counter	RF	TP2	RF	L19	128.700MHz (T,W) 129.700MHz (K,M,X) (f-16.3MHz)	Within +100Hz
	2) 5kHz switch ON					TC4	128.705MHz (T,W) 129.705MHz (K,M,X)	
	3) REV (T,W) only f = 145.00MHz OFF SET switch REV 5kHz Switch OFF				RF	L20	128.100MHz	
	4) 5kHz switch ON				RF	TC5	128.105MHz	

ADJUSTMENT

TX Section


Item	Condition	Measurement			Adjustment			Specifications/ Remarks			
		Test- equipment	Unit	Ter- minal	Unit	Part	Method				
1. Power output adjustment	1) f = 145.00MHz (T,W) f = 146.00MHz (K,M,X) ANT : Connect a power meter HI/LO : HI Transmit Power supply : 7.2V	DC AM			RF	L10- 13 TC1	MAX				
		Power meter DC AM (1A)		ANT	RF	TC1- 3	MAX	1.2W or more 600mA or less			
	2) f = 144.00MHz HI/LO : HI HI/LO : LO	Power meter					Confirm	1.0W or more 600mA or less			
							Confirm	0.1-0.2W Approx. 300mA			
	3) f = 145.98MHz (T,W) f = 147.98MHz (K,M,X) HI/LO : HI HI/LO : LO	Power meter					Confirm	1.0W or more 600mA or less			
							Confirm	0.1-0.2W Approx. 300mA			
2. Deviation adjustment	1) ANT : Power meter and linear detector, use capaci- tor 10μF/16V between AG output to MIC terminal f = 145.00MHz (T,W) f = 146.00MHz (K,M,X) AG : 1kHz, 50mV Transmit	Power meter Linear detector			IF	VR1	4.5kHz	4.5kHz±0.1kHz			
	2) AG : 1kHz, 5mV						Confirm	3-3.5kHz			
3. Tone encoder (K2,M3,M4) Type only	1) Push the "3" and "6" key.	Linear detector f. counter			DTMF	VR1	3.0kHz	Within ±0.5kHz			
	2) Push the "2" and "3" key.		DTMF	TON			Confirm. freq.	1471.9Hz±5Hz			
4. Tone (T,W) type only	1) (T) type only : Shorted C7 (Tone unit) Transmit Tone switch : ON				TONE	VR1	1750Hz	Within ±17.5Hz			
							Confirm. DEV	2.5kHz or more			
5. Option tone unit (TU-6) used (K,M,X)	1) Transmit Tone switch : ON				(TU-6)	VR1	0.5kHz	0.5-0.6kHz			
6 TX f adjustment	1) f = 145.00MHz (T,W) f = 146.00MHz (K,M,X) OFF SET switch : "S" Transmit	Power meter f. counter			RF	L21	145.00MHz (T,W) 146.00MHz (K,M,X)	Within ±100Hz			
						TC6	145.005MHz (T,W) 146.005MHz (K,M,X)				
	L22					144.400MHz (T,W) 145.400MHz (K,M,X)					
	3) f = 145.00MHz (T,W) f = 146.00MHz (K,M,X) OFF SET switch : " " Transmit					TC7	144.405MHz (T,W) 145.405MHz (K,M,X)				
						L20	146.600MHz				
	4) 5kHz Switch : ON					TC5	146.605MHz				
	5) (K,M,X) type only f = 146.00MHz OFF SET switch : "+" Transmit										
	6) 5kHz switch : ON										




ADJUSTMENT

RX Section


Item	Condition	Measurement			Adjustment			Specifications/ Remarks
		Test-equipment	Unit	Terminal	Unit	Part	Method	
1 Sensitivity	1) f: any	f.counter	IF	Q1- 2			Confirm	15.845MHz±240Hz
	2) SSG : 145.04MHz (T,W) 146.04MHz (K,M,X) -4~-6dBμ MOD: 1kHz DEV, 5kHz	SSG AF V.M Oscillo- scope 8Ω Dummy load		EXT SP	RF	L5-B L9,35, 36	MAX	
	SSG 0dBμ				IF	L1	MAX	
S/N	3) f = 144.00-147.99MHz (K,M,X) f = 144.00-145.99MHz (T,W)						Confirm	S/N 28dB or more



TOP VIEW



BOTTOM VIEW




BT-2 (AAA MANGANESE/ALKALINE BATTERY CASE)/ EB-2 (EXTERNAL C MANGANESE/ALKALINE BATTERY CASE)/ PB-21 (Ni-Cd BATTERY)

BT-2 OUTSIDE VIEW




BT-2 DISASSEMBLY




BT-2 PARTS LIST

Parts No.	Re- marks	Description	Ref. No.
A02-0677-02	*	Battery case	1
A02-0678-03	*	Battery case cover	2
E23-0451-04		Terminal board (A) x 2	3
E23-0452-04		Terminal board (B) x 6	4

EB-2 OUTSIDE VIEW



PB-21 OUTSIDE VIEW



PB-21 SPECIFICATIONS


Output voltage 7.2V
 Charging current 36mA (ordinary charging for approx. 8hrs.)
 Charging current 180mA
 Dimensions 57 (W) x 71 (H) x 14 (D) mm
 Weight Approx. 80g

EB-2 PARTS LIST

Parts No.	Re- marks	Description	Ref. No.
A02-0677-02	*	Battery case	
A02-0678-03	*	Battery case cover	
E23-0451-04		Terminal board (A) x 2	
E30-1793-05	N*	Cord ass'y	
H25-0103-04		Protective bag (Hard case)	
H25-0096-04		Protective bag (Battery case)	
J21-4164-04	N*	Fied plate (Cord bushing)	

DC-21 (DC-DC CONVERTER)/SC-8/8T (SOFT CASE)

DC-21 OUTSIDE VIEW



SC-8 OUTSIDE VIEW



DC-21 SPECIFICATIONS

Input voltage	13.8V DC (12–16V)
Output voltage	8V DC $\pm 5\%$
Output current	900mA (at input voltage of 13.8V DC with max. load)
Weight	Approx. 260g

DC-21 PARTS LIST

Parts No.	Re- marks	Description	Ref No
A02-0677-02	*	Battery case	
A02-0678-03	*	Battery case cover	
E03-0203-05		DC jack	J1
E23-0451-04		Terminal board (A) x 2	
E30-1791-05	N	Cord with plug	
E30-1796-05		Cord with cigarette plug and fuse	
F05-2023-05		Fuse 2A	
J42-0439-05		Cord bushing	
L15-0305-05		Choke coil 1mH	L1
NJM7808A		IC	IC1
SLH 34 VC3		LED (Red)	D3
U05B		Diode	D1
V06C		Diode	D2


SC-8T OUTSIDE VIEW



SC-8/8T PARTS LIST

Parts No.	Re- marks	Description	Ref. No.
J19-1408-04	N	Belt hook	

DC-21 SCHEMATIC DIAGRAM



SMC-30 (SPEAKER MICROPHONE)/
TU-6 (PROGRAMMABLE TONE ENCODER) TH-21A/AT ONLY




SMC-30 OUTSIDE VIEW

SMC-30 PARTS LIST

Parts No	Qty	Description	Ref. No
E30-1789-05	N	Coiled cord ass'y	
J19-1360-08		Cup metal fitting	
J42-0429-08		Cord bushing	
K29-3035-08	N	P.T.T knob	
S50-1408-08		Micro switch	
TU/-0219-08		Speaker	
T97-024-08		Electret microphone	


SMC-30 SPECIFICATIONS

- **SPEAKER**
 - Speaker 40mmφ
 - Max. Input 0.5W
 - Input Impedance 8Ω
- **MICROPHONE**
 - Type Electret condenser
 - Sensitivity -67dB
 - Output Impedance 2kΩ
 - Frequency response 200Hz~5kHz
 - Operating temperature .. -20°C~+60°C
 - Dimensions 51W x 34 x 33D (mm)
(Projections excluded)
 - Weight 130g (Code included)



TU-6 SCHEMATIC DIAGRAM

TU-6 (X52-1320-10)



Q1 : MX315
Q2 : 2SC2412K(Q) or 2SC2712(Y)

TU-6 (PROGRAMMABLE TONE ENCODER) TH-21A/AT ONLY


TU-6 SPECIFICATIONS

Oscillator frequency 1MHz ± 0.1%
Usable frequency range 3/ E1A
Specification Group Frequencies
(67.0-250.3Hz)
Weight 3g

TU-6 TONE FREQUENCY CHART

Setting the frequency

Cut and connect pins 1-6 of the IC to the PC board pattern by so deriving to set the frequency.
● "0" in the table indicates the connection.
● "1" in the table indicates the disconnect on.



Program Level	Program Level	Program Level	Program Level	Program Level	Program Level
1	2	3	4	5	6
1	1	1	1	1	1
2	1	1	1	1	1
3	1	1	1	1	1
4	1	1	1	1	1
5	1	1	1	1	1
6	1	1	1	1	1
7	1	1	1	1	1
8	1	1	1	1	1
9	1	1	1	1	1
10	1	1	1	1	1
11	1	1	1	1	1
12	1	1	1	1	1
13	1	1	1	1	1
14	1	1	1	1	1
15	1	1	1	1	1
16	1	1	1	1	1
17	1	1	1	1	1
18	1	1	1	1	1
19	1	1	1	1	1
20	1	1	1	1	1

TU-6 PARTS LIST


Parts No	Qty	Description	Ref. No	Qty
B50-4178-00	N	Instruction manual		
G13-0806-04	N	Cushion		
H25-0022-04		Protective bag		
X52-1320-10	N	Tone unit		

TONE UNIT (X52-1320-10)

CC73FBCH1H30J	Chip cap	33p	C1, 2	2
CE04CW1A100M	Electro	10 10V	C6	
CK73FB1E103K	Chip cap	0.01	C3	1
CK73FB1E223K	Chip cap	0.022	C5	1
CK73FB1H102K	Chip cap	0.001	C7	
C90-0888-05	Crystal	0.1 16V	C4	
L77-0982-05	Crystal	1MHz	X1	1
RD73FB2A103J	Chip res std	10kΩ	R6	
RD73FB2A105J	Chip resistor	1MΩ	R1	
RD73FB2A223J	Chip resistor	22kΩ	R2	1
RD73FB2A224J	Chip resistor	220kΩ	R4	
RD73FB2A473J	Chip resistor	47kΩ	R3	1
R12-3449-05	Trim. pot	10kΩ(1B)	VR1	1
R92-0670-05	Chip res std	0Ω	R5	1
MX315	C		Q1	1
2SC1412K(Q) or 2SC2712(Y)	TR		Q2	1


TU-6 PC BOARD VIEW

TONE UNIT (X52-1320-10) Foil side view




Q1 : MX315 Q2 : 2SC2412K(Q) or 2SC2712(Y)


MX-315




WIRING/REFERENCE DATA




RX SENSITIVITY




INTER MODULATION




DEVIATION




OUTPUT POWER



NEAR SPURIOUS RESPONSE



HARMONICS SPURIOUS RESPONSE




CARRIER FREQ.: 145.50MHz
RF POWER: 1.6W
SCAN WIDTH: 2MHz/DIV
BAND WIDTH: 30kHz
SCAN TIME: 0.1 SEC
VIDEO FILTER: 10kHz
INPUT ATT.: 0dB
LOG REF LEVEL: -10dBm
10dB/DIV

CARRIER FREQ.: 145.50MHz
RF POWER: 1.6W
SCAN WIDTH: 100MHz/DIV
BAND WIDTH: 30kHz
SCAN TIME: 2 SEC
VIDEO FILTER: 10kHz
INPUT ATT.: 0dB
LOG REF LEVEL: -10dBm
10dB/DIV


The fundamental signal is reduced by HPF.
(fc: 240MHz)

Signal line — Control line — Common DC line Voltage measurement conditions $f_s = 145.50\text{MHz}$, RX no signal, () : TX.




TH-21A/AT SCHEMATIC DIAGRAM



IF UNIT (X48-1410-61)



RF UNIT (X44-1630-61)





SPECIFICATIONS

General

Frequency range	144 — 146MHz ; TH-21E, TH-21A (Oceania version only) 144 — 148MHz ; TH-21A/AT
Signal type	F3 (FM)
Operating temperature	-20°C ~ +50°C
Antenna impedance	50Ω
Power supply voltage	5.8V — 10.0V (rating voltage ; 7.2V)
Power consumption	At reception standby ; Less than 28mA At transmission (Hi) ; Less than 600mA (Low) ; About 300mA
Dimensions	57 (65.5) W x 120 (127.5) H x 28 (32) D mm The numbers in the parenthesis include projections parts.
Weight	Approx. 290g (including antenna and Ni-Cd batteries)

Transmitter section

Output power	Hi ; 1.0W, Low ; approx. 150mW
Modulation system	Reactance modulation
Max. frequency deviation	±5kHz
Unwanted reflection	Less than -60dB
Microphone	Condenser type

Receiver section

Reception system	Double superheterodyne
Intermediate frequency	1st ; 16.3MHz, 2nd ; 455kHz
Sensitivity	S/N more than 28dB at -6dBμ (0.5μV) input 12dB SINAD ; less than -12dBμ (0.25μV)
Squelch sensitivity	Less than 0.25μV
Selectivity	-6dB at more than 12kHz -40 dB at less than 28kHz
AF output	More than 250mW (8Ω load, distortion 10%)

Design and specifications subject to change without notice.

TRIO-KENWOOD CORPORATION

Shionogi Shibuya Building, 17-5, 2-chome Shibuya, Shibuya-ku, Tokyo 150, Japan

TRIO-KENWOOD COMMUNICATIONS

1111 West Walnut Street, Compton, California 90220, U.S.A.

TRIO-KENWOOD COMMUNICATIONS, GmbH

Rembrücker Str. 15, 6056 Heusenstamm West Germany

TRIO-KENWOOD ELECTRONICS, N.V.

Leuvensesteenweg 504 B-1930 Zaventem, Belgium

TRIO-KENWOOD (AUSTRALIA) PTY. LTD. (INCORPORATED IN N.S.W.)

4E Woodcock Place, Lane Cove, N.S.W. 2066, Australia